

Quick Reference Guide to CAP FM Radio Used in CAWG Aircraft

Turning on the Radio

Desired Action Procedure

Turn on radio	Coordinate with pilot so you are using COM 3 thru the audio panel Make sure EDIT switch is centered Turn MAIN (MN) volume knob-clockwise Turn volume MN Knob to middle (approx) Turn GUARD (GD) volume knob to middle (approx)
Clear Help screen	Toggle BRIGHTNESS switch once in either direction
Adjust screen brightness	Toggle BRIGHTNESS switch either direction as desired
Set display	Move DSIP switch to left (ID) position
Select channel	Move CHANNEL switch right or left (+ or -) to desired channel according to chart for repeaters
Set scan switch	Move SCAN switch to middle position
Set Guard frequency	Move GD1/GD2 switch to the GD1 position
Adjust volume controls	Turn MN and GD volume knobs to comfortable settings
Adjust Squelch	Press white SQ button: IN to hear weak signals, OUT for normal signals

Transmitting and Receiving

Receiving Move	Move SCAN switch to NORM as stated above. You are listening to 148.150 thru the repeater selected (The orange light to the right of the MN knob will come on when you are receiving thru the repeater) You are also listening to 148.150 simplex thru Guard 1 (The orange light to the right of the GD knob will come on when you are receiving thru the simplex receiver)
Transmit thru repeater	Key Push to Talk (PTT) switch (usually on your yoke)
Transmit on simplex	Move the SCAN switch down to GD TX (display screen should say channel 01 simplex) Key PTT switch (usually on your yoke)

NOTE: The **EDIT** switch should always be in the center position.

1 Mar 2001 by Capt. Woody McCauley